

+++now available+++

FUB & FUB-386 Upgrade

We are proud to announce to you our latest **product redesign** of our existing fuel hoses **FUB & FUB-386**.

The hoses are suitable for the **delivery of unleaded gasoline and diesel** fuels for cars, trucks, and tractors as well as for the **usage in engine compartments of trucks**.

With this **upgrade** the products now also meet the requirements of **SAE J30R2 & J30R6** (standards of the Society of Automotive Engineers), and are suitable for the usage with the **most common gasoline and diesel fuels** in the market. Additionally, the new hose design allows us to provide an **extended working pressure** of **12bar** with a **safety factor of 4:1** and offers a reduced **bending radius of 6xID** for better flexibility and bending behavior.

The most important upgrades at a glance:



Fulfils standards **SAE J30 R2 & SAE J30 R6**



Liner fulfils **RMA class A (highly oil resistant)** and is suitable for

- Diesel B7 (EN590:2017 standard diesel), B20, B100 (100% biodiesel)
- Unleaded fuel E5 (EN228:2017 standard fuel), E10, E85 and E100 (100% ethanol)



Higher **pressure rate** of **12 bar** with safety factor 4:1



Significantly reduced bending **radius of 6xID** instead of 10xID



Temperature resistance up to max. **+100°C** with a max. ambient temperature of **+120°C**



Higher **ozone resistance** of the hose-cover



New **branding text**: "SEMPERIT (S) FUB KRAFTSTOFF/FUEL ID PN 12 BAR **SAE J30R2 / SAE J30R6** MADE IN EU // // // // //"

For ordering our product, please [contact our expert team](#), we will gladly provide you with an offer.
More information can also be found on the respective datasheet, available on our [website](#).