










Tarspray - NBR - 16 bar - D - Wire/Textile



SPECIFICATIONS

Application	Suitable for use as tar spraying hose up to 180°C. Based on Norm EN 13482. The hose may be used for applications other than tar spraying at temperatures up to 110°C.
Feature	The design with a steel wire braid and overlaid textile braid insert ensures good layer adhesion and heat insulation. Electrical conductivity: Resistance $R < 10^6$ Ohm.
Temperature range	-35°C / +180°C [tar].
Safety factor	8,75 : 1 for tar
Tube	NBR, black, electrically conductive, smooth.
Reinforcement	Steel and textile braided.
Cover	CR, black, resistant to ozone and weather, abrasion resistant, electrically conductive, cloth impression.
Marking	continuous embossed tape: "SEMPERIT [S] TTS Teerspritz/Tarspray PN 16 bar".
Notice	ATTENTION: The hose may only be used at temperatures of up to 180°C in accordance with instructions. The application of solvents or the use of flame to remove tar is not permitted. The hose must be replaced even in the case of minor damage.

TECHNICAL DETAILS

 Article number	 Internal-Ø		 Wall width	 External-Ø	 Work. pressure [max.]	 Number of inserts	 Bending radius [min.]	 Weight approx.	 Coil length [max.]
	mm	inch	mm	mm	bar		mm	kg/m	m
48702 1960	19.0	3/4	6.0	31.0	16	2	190	0.80	40
48702 2570	25.0	1	7.0	39.0	16	2	250	1.10	40

Please note: Before using our products with new or untested media, or for applications that are not clearly indicated in the product information, written advice must be obtained from a specialist dealer or a Semperit application engineer. For safety reasons, all products must be inspected regularly for operational safety and replaced in the event of any damage [especially of the cover] or unusual signs of wear and tear. All products must be stored, handled, and maintained in accordance with all our respective instructions and DIN 7716:1982. The information in our catalogue as well as each individual datasheet is subject to change at any time without notice since we are constantly developing and improving our products and due to constant technical developments after the latest release date of the catalogue and/or individual datasheets. To always have the latest product and safety information make sure you visit our website [hoses.semperitgroup.com] regularly or contact one of our specialist dealers or a Semperit application engineer. All contracts concluded with us are exclusively subject to our general terms and conditions [available at semperitgroup.com]. Additional important general information about the range, choice and safe use of our products can be found at our website [hoses.semperitgroup.com] and must be followed without exception.

Important notice: Our catalogue and any individual datasheet have been prepared with great care in order to provide you with all the information you need. The information contained therein is based on the state-of-the-art industrial technology and many years of experience and testing; whenever indicated for a certain product, we also confirm conformity with the resistance requirements of the media listed in ISO TR 7620:2005(E). However, the individual conditions of storage, maintenance and use decisively affect the safe and durable use of each product. The quality and safety of our products as indicated in the catalogue or individual datasheets are therefore strictly subject to your continuous observance of all specifications and restrictions in our written product information and applicable laws and standards, the specifications regarding resistance to chemicals and our cleaning procedures. We reject any liability for safety issues or other consequences due to improper product choice, maintenance, or handling [e.g. squashing, rupturing, stretching, or filling with non-approved media]. Our products must not be used in airplanes or other aerial vehicles under any circumstance. Products delivered by us to the USA are manufactured according to IRPM-IP2, unless specified otherwise. All other hoses are manufactured according to EN ISO 1307:2008, unless specified otherwise. Our products are not designated for the sale to the general public and do not fulfill the conditions for "GS-certification", unless stated otherwise in the product datasheet.